Waterproof 4 Channel Constant Voltage Power Repeater

Model No.: EV4-WPS

IP67 waterproof/4 Channel/PWM signal input/Constant voltage output/3KV optoelectronic isolation

Features

- Waterproof 12-36V constant voltage power repeater with IP67 rating, suitable for outdoor and damp environment.
- 4 channel, 5A per channel.
- To receive PW/M signal control.
- Power repeater in series or in parallel to expand output unlimitedly.
- Apply to single color, dual color, RGB or RGBW constant voltage LED strip or module.





CE RoHS emc LVD

Technical Parameters

| Input and Output | | Safety and EMC | | Warranty and Protection | |
|------------------|------------------|----------------------|---------------------------|--|-------------------|
| Input voltage | 12-36VDC | FARC : 1 LIENAGY | ETSI EN 301 489-1 V2.2.3 | Warranty | 5 years |
| Input current | 20.5A | EMC standard (EMC) | ETSI EN 301 489-17 V3.2.4 | Reverse Polarity Over-heat Over-load Short circuit | Reverse Polarity |
| Input signal | PVVM | Safety standard(LVD) | EN 62368-1:2020+A11:2020 | | |
| Output voltage | 4 x (12-36)VDC | Radio Equipment(RED) | ETSI EN 300 328 V2.2.2 | | |
| Output current | 4CH,5A/CH | Certification | CE,EMC,LVD | Environment | |
| Output power | 4 × (60-180)W | Package | Package | | Ta: -30°C ~ +55°C |
| Output type | Constant voltage | Size | L165 x W98 x H72mm | Case temperature (Max.) | T c:+75°C |
| | | Gross weight | 0.492kg | IP rating | IP67 |


Mechanical Structures and Installations






Wiring Diagram

• Parallel connection





Malfunctions analysis & troubleshooting

| Malfunctions | Causes | Troubleshooting |
|--|--|---|
| No light | No power. Wrong connection or insecure. | Check the power. Check the connection. |
| Wrong color | 1. Wrong connection of $R/G/B/W$ wires. | 1. Reconnect R/G/B/W wires. |
| Uneven intensity between front and rear, with voltage drop | Output cable is too long. Wire diameter is too small. Overload beyond power supply capability. Overload beyond controller capability. | Reduce cable or loop supply. Change wider wire. Replace higher power supply. Add power repeater. |

Safety & Warnings

- 1. The product shall be installed and serviced by a qualified person.
- 2. Good heat dissipation will prolong the working life of the controller, Please ensure good ventilation.
- 3. Please check if the output voltage of any power supplies used comply with the working voltage of the product.
- 4. Ensure all wire connections and polarities are correct and secure before applying power to avoid any damages to the LED lights.
- 5. If a fault occurs please return the product to your supplier. Do not attempt to fix this product by yourself.

User Manual Ver 1.0.0 — 2